

Description: Importing or Exporting Workbench Configuration and mass data manipulation

OS Requirement: Windows Server 2003 x64 / Vista x64 / Server 2008 x64 / Windows 7 x64 / Server 2008 R2 x64

General Requirement: General understanding of GENESIS64 functionality and an installation of GENESIS64.

Introduction

Workbench is the central configuration tool; each provider placed inside it has its own configuration saved in database. This document will describe how to import and export any provider configuration inside Workbench and manipulate the massive amount of data. For more information follow the training manual for GENESIS64.

Open Workbench:

1. To open Workbench go to Start → All Programs → ICONICS → Workbench.




Figure 1 – Workbench

2. Open any configuration, we will use Unified Data Manager configuration as an example.

Copy, Paste and Multiply items:

3. Right click on root any item to open popup menu. Now you should be able to copy, paste or multiply items like shown in figure below.




Figure 2 – Copy, Paste, Multiply functions

Import/Export configurations:

You can Import or Export whole configuration of a provider under the “HOME” tab on the ribbon or just part of the configuration from each provider available inside the Workbench. Simply right click on level you wish to import / export and select Import or Export item from popup menu, as shown in Figure 3.




Figure 3 – Import Export items

Export Settings:

Export properties will show you the choices for export to XML, Excel file or CSV including “Delimiter” settings.




Figure 4 –Export Settings