

Description: Guide to transferring your license using the ICONICS website

OS Requirement: Windows XP / Windows Vista / Windows 7 / Windows 8 / Windows Server 2003 / Windows Server 2008 / Windows Server 2008 R2 / Windows Server 2012

General Requirement: A valid license on the source machine and installation of GENESIS32 licensing on the destination machine.

Introduction

From time to time you may need to upgrade your machines and you will need to move the GENESIS32 license from the old machine to the new machine. This document will describe how to transfer the license via the ICONICS website.

Removing Your License

1. Go to www.iconics.com and launch the Web Licensing Utility Site by clicking on Support in top header and then “License product”.
2. Select Software and log in with your user name and password.

NOTE: If you do not have a user name and password pair or that you have forgotten your user name and password, you can simply register for one.

3. Once you have logged into the website, click on the “Kill license” link.
4. You will see at the top of the page a dialog box similar to Figure 1



Figure 1 - Site Key/Kill Code Dialog

5. Open your License Utility on your source machine
6. Once the License Utility is opened, go to Actions → Authorize License and click Kill Current License button
7. A few messages will pop up asking you if you really want to kill the license, confirm that you do.
8. You will then get a window with your site key and kill code in it.
9. Copy the Site Key in to the Site Key field on the webpage and the Kill Confirmation Code into the Kill Code field on the webpage and click on the “Next” button in the webpage.
10. You will then get a message confirming that the license has been successfully removed.

Licensing Your New Machine

1. On the machine where you want the GENESIS32 license to reside, open the License Utility
2. Once the License Utility opens, go to Actions → Authorize License
3. You will see a dialog come up with a Site Code and a blank Site Key as show in Figure 2. Do NOT close this window during this entire process, it will generate a new Site Code if you do and the site key generated on the website will not match.




Figure 2 - License Authorization Dialog

4. Go to www.iconics.com and launch the Web Licensing Utility Site by clicking on Support in top header and then “License product”.
5. Select Software and log in with your user name and password.
6. Once you have logged into the website, click on the “New license” link.
7. Enter your Customer Key and Product Registration Number for the product.

NOTE: Your Customer Key and Product Registration Number are usually on the back of the original disk that we send you.

8. Click the “Next” link once you have entered all of your Product registration number, you can enter up to ten.
9. In the next screen, you will see a list of the products that is available for you to license; check all the products that you would like to license and copy and paste the Site Code onto the website from your license utility. Click on the “Next” link.
10. This page shows you a summary of what will be in your license, check to make sure everything is correct and click on the “Generate Key” button
11. Save the License File (a *.glic file) and browse for it in the License Authorization dialog.
12. Once you put a file in, the Activate License button will become available, click on the button to activate the license.
13. You should now see the license information by going to View → License.