

Description: Guide to configure the GraphWorX32 ActiveX toolbar

OS Requirement: Win 2000, XP Pro, Server 2003, Vista, Server 2008, Windows 7

General Requirement: installation of GENESIS32 v9.x

Introduction to the ActiveX toolbar

The ActiveX toolbar, shown below, enables you to insert various ActiveX objects into the GraphWorX32 display. Click the OLE button to browse for a list of objects.



Figure 1 - ActiveX Toolbar in GraphWorX32

Configure GraphWorX32 ActiveX Toolbar

ActiveX controls can be inserted in the display via the OLE button on the ActiveX toolbar. You can remove ActiveX buttons from the toolbar.

1. Right-clicking on the toolbar to open the Customize Toolbar dialog box.
2. Select the ActiveX from the list on the right, and then click on the “Remove” button. Alternatively, you can remove a button from the toolbar by clicking the button on the toolbar while pressing the shift key and dragging the button off the toolbar.




Figure 2 - ActiveX Customize Toolbar

You can also configure the ActiveX toolbar in GraphWorX32 by editing the IcoSetup.ini file. These settings are made when a user wants to customize the GraphWorX32 ActiveX Toolbar and show only requested shortcuts and icons.

1. Open IcoSetup.ini file. It may be located in different directories depending on your operating system.
2. You may find entries similar to those below in the file

```
[GWX32\OEM Information\ActiveX Toolbar Default Info]
ProgID_1=GWXVIEW32.GWXview32Ctrl.1
ProgID_2=TWXViewer.TWXViewerCtrl.1
ProgID_3=AWXview32.AWXview32Ctrl.1
ProgID_4=ICONICS.AWXRep32Ctrl.1
ProgID_5=AwxInd32.AwxIndicator.1
ProgID_6=GWXGAUGE.GWXGaugeCtrl.1
ProgID_7=GWXSWITCH.GWXSwitchCtrl.1
ProgID_8=GWXSLIDER.GWXSliderCtrl.1
ProgID_9=DBGRID.DBGrid32Ctrl.1
Number of ProgIDs=9
```

3. You only need to add requested entries for specific ActiveX controls in the order you wish to see them and at the end write the total number of the controls you have.
4. Open GWX and right-clicking on the toolbar
5. This opens the Customize Toolbar dialog box.
6. Click on the “Reset” button and all setting will be done according the IcoSetup.ini file