


# CyberPower®

## POWER BANK

CP2500NLS

## PRODUCT GUIDE

### PRODUCT VIEW:



No	ITEM	DESCRIPTION
1	LED Charge Indicator	LED is blinking during charging, and will light up when the power bank is fully charged. LED will be off when the battery is out of power.
2	Micro USB Input Port	5V/0.8A
3	USB Output Port	5V/1A

Note: When the Power Bank is connected to the power, the LED indicator will blink, indicating the charging status.

### INTRODUCTION

The Power Bank (CP2500NLS) is a high capacity rechargeable lithium-ion battery designed for powering mobile devices such as phones, MP3 players, and handheld gaming devices while away from other power sources.


### SUGGESTED - PRIOR TO FIRST USE

It is recommended that you charge your CP2500NLS for 6 hours to insure a full charge.

### CHARGING THE POWER BANK

Charge the Power Bank by included charging cable. When charging the Power Bank, the LED indicator will light up automatically.

Recharge the CP2500NLS every 3 months when not in use to maintain peak battery performance. The battery capacity may decline after 300 charging cycles.



### SPECIFICATIONS

Battery Capacity: 2000mAh

Rated Input: DC 5V 0.8A

Rated Output: DC 5V 1A

Fully Charging Time: ~4 Hours

Dimensions: 106.6\*23.6\*22.6 mm

Weight: 65 g

Environment: Storage: 14 to 122°F (-10 to 50°C)

Operation: 32 to 104°F (0 to 40°C)

### TROUBLESHOOTING

Problem	Possible Cause	Solution
Power Bank does not power the device	1. The device is drawing too much power.	Check the power specification of the device before charging with the CP2500NLS.
	2. The battery is out of power.	Charge the Power Bank.
Power Bank does not recharge	1. Incorrect connection between charger and Power Bank.	Re-attach the USB connector to the socket.
	2. No power from the source.	Check that power is provided.

## SAFETY INFORMATION/CAUTION

Before using the Power Bank, please read the following warnings carefully. Use the product according to the procedures described in this manual. Failure to follow these safety precautions may result in fire, explosion, electrical shock or other dangers.

1. Store between 14 to 122°F (-10 to 50°C). Operate between 32 to 104°F (0 to 40°C).
2. Do not immerse this product in water or other liquids, as such use may result in fire or electrical shock. If water or other liquids enter the battery interior, unplug the product immediately from any attached power source or device.
3. Do not use this product with wet hands. Moisture in or on this product may result in electrical shock.
4. Store this product in a cool and dry environment when not in use.
5. Do not puncture this product. Puncturing the battery may cause the release of harmful substances.
6. It is normal for the Power Bank to become warm during charging.
7. Ensure that all users read these warnings and instructions before using.
8. Please recycle Power Bank in accordance with local environmental laws and regulations.
9. Do not dismantle, open or shred secondary cells or batteries.
10. Do not expose cells or batteries to heat or fire. Avoid storage in direct sunlight.
11. Do not short-circuit a cell or a battery. Do not store cells or batteries haphazardly in a box or drawer where they may short-circuit each other or be short-circuited by other metal objects.

4

27. Secondary cells and batteries give their best performance when they are operated at normal room temperature (20 °C ± 5 °C).
28. Retain the original product literature for future reference.
29. Use only the cell or battery in the application for which it was intended.
30. When possible, remove the battery from the equipment when not in use.
31. Dispose of properly.

According to the Instructions.

This product is safe for regular use under normal conditions. As with any device using electrical power, some situations may be unsafe and injuries or damages could result. To minimize or avoid unsafe conditions, please read and follow the instructions before using.

6

12. Do not remove a cell or battery from its original packaging until required for use.
13. Do not subject cells or batteries to mechanical shock.
14. In the event of a cell leaking, do not allow the liquid to come in contact with the skin or eyes. If contact has been made, wash the affected area with copious amounts of water and seek medical advice.
15. Do not use any charger other than that specifically provided for use with the equipment.
16. Observe the plus (+) and minus (-) marks on the cell, battery and equipment and ensure correct use.
17. Do not use any cell or battery which is not designed for use with the equipment.
18. Do not mix cells of different manufacture, capacity, size or type within a device.
19. Keep cells and batteries out of the reach of children.
20. Seek medical advice immediately if a cell or a battery has been swallowed.
21. Always purchase the correct cell or battery for the equipment.
22. Keep cells and batteries clean and dry.
23. Wipe the cell or battery terminals with a clean dry cloth if they become dirty.
24. Secondary cells and batteries need to be charged before use. Always use the correct charger and refer to the manufacturer's instructions or equipment manual for proper charging instructions.
25. Do not leave a battery on prolonged charge when not in use.
26. After extended periods of storage, it may be necessary to charge and discharge the cells or batteries several times to obtain maximum performance.

5

**CyberPower Systems, Inc.**

[www.cyberpower.com](http://www.cyberpower.com)

7

K01-0000506-00